

# PAMC-204/PAMC-204-RJ

## PIEZO ASSIST MOTOR CONTROLLER OPERATION MANUAL



All Rights Reserved



## Technical Support Contacts

### Tokyo, Japan

#### Mechano Transformer Corporation

4F BUILDX No.3,

2-7-12, Iwamoto-cho, Chiyoda-ku,

Tokyo 101-0032 Japan

Tel:03-5297-6088 FAX:03-5297-608

### Mechano Transformer Corporation Calling Procedure

If there are any defects in material or workmanship or any failure to meet specifications, promptly notify Mechano Transformer Corporation Department by calling 03-5297-6088 or by visiting our website at [www.mechano-transformer.com](http://www.mechano-transformer.com) within the warranty period, return the product to Mechano Transformer Corporation. Mechano is not responsible for damage occurring in transit and is not obliged to accept products returned if the warranty seals are broken.

E-mail: [info@mechano-transformer.com](mailto:info@mechano-transformer.com)

When contacting Mechano Transformer Corporation for technical support, it is essential to provide specific details to help the customer care representative diagnose:

1. Your Contact Information, including your name, phone number, and email address
2. Product's serial number or original order number
3. Describe the issue, specifying whether it relates to hardware or software.

Additionally, be prepared to answer diagnostic questions, such as whether the system is used for manufacturing or research and development, and what the system's state was before the issue occurred. If the problem has been encountered before, mention how frequently it happens. It is also important to indicate whether the system can still operate despite the issue or if it has become non-functional. Lastly, identify any changes or events that may have contributed to the problem, such as recent updates, modifications, or environmental factors. Providing these details will allow the technical support team to analyze the situation thoroughly and offer an effective solution.



## EU Declaration of Conformity (DoC)

**We**

Company name: Mechano Transformer Corporation  
Postal address: 4F BUILDX No.3, 2-7-12, Iwamoto-cho, Chiyoda-ku  
Postcode: 101-0032  
City: Tokyo, Japan  
Telephone number: +81-3-5835-0108

**declare that the DoC is issued under our sole responsibility and belongs to the following product:**

Apparatus model/Product: Piezo Assist Motor and Piezo Drive Motor  
Number: PAMwxyz (w=3-6.5 or 6-13, x=R or Null, y=-C, -C1 or Null, z=N, V or Null),  
PDM-6.5ACTu(u=Null, R or R-C1), PDM-13ACTv(v=Null, R, R-C1 or R-C2)  
Category: Electrical equipment for measurement, control and laboratory use

**The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:**

EMC Directive 2014/30/EU      RoHS Directive 2011/65/eu  
Low Voltage Directive (LVD) 2014/35/EU

**The following harmonised standards and technical specifications have been applied:**

**Title, Date of standard/specification:**

EMC EN61326-1:2021, Class A      EMC EN61326-1:2021, Industrial  
RoHS EN IEC 63000 : 2018      LVD EN 61010-1:2010+A1:2019

**Signed for and on behalf of:**

Japan      2025-6-5  
Place of issue      Date of issue



Chee Sze Keat  
Chief Executive Officer  
Mechano Transformer Corporation  
4F BUILDX No.3, 2-7-12, Iwamoto-cho, Chiyoda-ku, Tokyo  
101-0032 Japan

## TABLE OF CONTENTS

<b>1</b>	<b>Product Overview.....</b>	<b>1</b>
<b>2</b>	<b>Safety Precautions.....</b>	<b>2</b>
<b>2.1</b>	<b>Definitions and Symbols.....</b>	<b>2</b>
<b>2.1.1</b>	<b>Electric Shock.....</b>	<b>2</b>
<b>2.1.2</b>	<b>Potential Burn Hazard .....</b>	<b>2</b>
<b>2.1.3</b>	<b>ON Switch Symbol.....</b>	<b>3</b>
<b>2.1.4</b>	<b>OFF Switch Symbol.....</b>	<b>3</b>
<b>2.1.5</b>	<b>GROUND .....</b>	<b>3</b>
<b>2.2</b>	<b>Warnings and Cautions.....</b>	<b>4</b>
<b>2.3</b>	<b>Locations of Labels and Warnings.....</b>	<b>4</b>
<b>3</b>	<b>Compositions .....</b>	<b>5</b>
<b>3.1</b>	<b>Included Items .....</b>	<b>5</b>
<b>3.2</b>	<b>Optional Accessories .....</b>	<b>5</b>
<b>4</b>	<b>Weight and Dimensions.....</b>	<b>6</b>
<b>4.1</b>	<b>PAMC-204.....</b>	<b>6</b>
<b>4.2</b>	<b>PAMC-204-RJ .....</b>	<b>7</b>
<b>5</b>	<b>Product Specifications .....</b>	<b>8</b>
<b>5.1</b>	<b>Electrical Characteristics.....</b>	<b>8</b>
<b>5.2</b>	<b>Communication Specifications .....</b>	<b>8</b>
<b>5.3</b>	<b>PAMC-204 Parts.....</b>	<b>9</b>
<b>5.4</b>	<b>PAMC-204-RJ Parts .....</b>	<b>10</b>
<b>6</b>	<b>Control Manual.....</b>	<b>12</b>
<b>6.1</b>	<b>Before Using.....</b>	<b>12</b>
<b>6.2</b>	<b>Driver setup .....</b>	<b>12</b>
<b>6.2.1</b>	<b>Single Driver Setup.....</b>	<b>12</b>
<b>6.2.2</b>	<b>Daisy Chain Setup .....</b>	<b>13</b>
<b>6.3</b>	<b>Controlling the driver. ....</b>	<b>15</b>
<b>6.3.1</b>	<b>Using Tera Term.....</b>	<b>15</b>
<b>6.4</b>	<b>Command List .....</b>	<b>23</b>
<b>6.5</b>	<b>Command Description .....</b>	<b>24</b>
<b>6.6</b>	<b>Error Description.....</b>	<b>42</b>

# 1 Product Overview

PAMC-204 and PAMC-204RJ driver are specifically designed for driving Piezo Assist Motor (PAM). One driver can be connected to 4 motors and can drive 1 motor at a time. By using USB and tools capable of serial communication like Tera Term, the driver can be controlled from PC easily. The output voltage of PAMC-204 can be adjusted with command to get more precise movement.

## Features of PAMC-204/PAMC-204-RJ


- Stackable driver for compact installment
- Plug-and-play USB interface
- RS485 interface
- Overheat protection
- Adjustable output for different movement speed

## 2 Safety Precautions

The following terms and symbols are used in this documentation and appear on the Model PAMC-204 and PAMC-204RJ Controller/Driver where safety related issues occur.

### 2.1 Definitions and Symbols

#### 2.1.1 Electric Shock



The Electrical Shock Symbol shown in this manual and on the product is a warning sign for hazardous high voltage. Mishandling the equipment could lead to serious damage, injury, or even death. Please handle with caution and follow all safety guidelines.

#### 2.1.2 Potential Burn Hazard



The Hot Surface Symbol shown in this manual and on the product warns of high temperatures. Touching the surface may cause burns or injury. Please handle with care and follow all safety precautions.

### **2.1.3 ON Switch Symbol**



The symbol shown in the figure indicates the power switch position on the Model PAMC-204. It signifies that the device is in the Power On state.

### **2.1.4 OFF Switch Symbol**



The symbol shown in the figure indicates the power switch position on the Model PAMC-204 and PAMC-204RJ. It signifies that the device is in the Power Off state.

### **2.1.5 GROUND**




The symbol above appears on the Model PAMC-204/PAMC-204RJ to indicate the screw to be used to ground the case of the unit. This symbol identifies the frame or chassis terminal.

## 2.2 Warnings and Cautions

1. Please read and understand the User Manual before usage.
2. Only experienced technicians should handle the driver.
3. Do not disassemble or modify the driver.
4. Do not use the driver near any flammable materials or locations with high moisture or humidity.
5. Turn off the driver power supply if abnormal smell, noises, overheating, heat dissipation are detected.
6. Ensure the driver's power switch is switched off before connecting to power source.
7. Do not turn on the driver after dropping or applying shock to driver.
8. Do not touch the PAM during the operation.
9. Do not operate with wet hands.

## 2.3 Locations of Labels and Warnings.



## 3 Compositions

---

### 3.1 Included Items

---

The following items are included in the standard package:

1. PAMC-204 Driver
2. USB Type A – Type B Cable (USB cable)

### 3.2 Optional Accessories


---

1. MT-UNI345-2419-PL03B (DC 24V 1.9A Power Adapter)
2. MT-DCB-AKI08 (3.5mm audio cable for 485 communication)
3. DC-PWR-LINK-200 (2.1mm DC connector 200mm cable)

## 4 Weight and Dimensions


### 4.1 PAMC-204

Weight	350 g (12.35 oz)
Dimensions	(L x W x H) 5.84 in x 3.61 in x 1.06 in 148.3 cm x 91.7cm x 26.8 cm



## 4.2 PAMC-204-RJ

Weight	350 g (12.35 oz)
Dimensions	(L x W x H) 5.84 in x 3.61 in x 1.06 in 148.3 cm x 91.7cm x 26.8 cm



## 5 Product Specifications

### 5.1 Electrical Characteristics

Electrical Characteristics	PAMC-204/204 RJ
Input Voltage	24 V
Current consumption	0.5 A max
Operating temperature	5~40 °C
Storage temperature	-20~60 °C <sup>1)</sup>
Storage humidity	20~80%
Weight	0.35kg
Number of axis	4
Maximum frequency	1500Hz
Output Voltage	70~150V <sup>2)</sup>


Refer Below:

- 1) No condensation
- 2) Output voltage adjustable by command

### 5.2 Communication Specifications



Communications	PAMC-204/204 RJ
Interface	USB Serial/485 protocol
Baud Rate	115200 bps
Data Bit	8 Bit
Parity	None
Stop Bit	1 Bit
Flow Control	None
Delimiter	CR + LF


### 5.3 PAMC-204 Parts



Item No	Parts Description
1	Axis 1
2	Axis 2
3	Axis 3
4	Axis 4
5	DC Power Terminal
6	Switch
7	USB Port
8	485 Communication Port
9	Case Ground

### 5.4 PAMC-204-RJ Parts






Item No	Parts Description
1	Axis 1
2	Axis 2
3	Axis 3
4	Axis 4
5	DC Power Terminal
6	Switch
7	USB Port
8	485 Communication Port
9	Case Ground

## 6 Control Manual

### 6.1 Before Using

All drivers' address in factory setting is **E01**. In the case of using the driver in the daisy chain set up, change the address of each driver using the following steps.




1. Connect only one driver to the PC. (Same as single driver setup)
2. Use Tera term or a similar tool to communicate with the driver.
3. Use the command "SETADDRXX" to change the address. (XX: 01 ~ 32, refer to section 6.4 and section 6.5 for more details on command)

```
E01
E010K
SETADDR02
SETADDR02
E02
E020K
```

### 6.2 Driver setup


#### 6.2.1 Single Driver Setup




1. Connect the driver to the power adapter (UNI345-2419), PC and motor.
2. Turn on the power switch.
3. Open serial connection to driver using Tera Term or similar tool.
4. Send command to the driver.

**Note: Ensure that the driver's power switch is switched off before connecting power source.**

### 6.2.2 Daisy Chain Setup





1. Connect power adapter (UNI345-2419) to the DC power terminal of the first driver and link the DC power terminal of other two drivers with the DC connector.
2. Connect the drivers to the motors.
3. Connect the first driver's USB port to the PC.
4. Connect all the drivers' RS485 port using the cable.
5. Send command to the respective driver.

**Note: The optional item MT-UNI345-2419-PL03B and DC-PWR-LINK-200 can only support up to 3 drivers at a time. For 4 or more drivers, please use additional power adapters and cables.**

## 6.3 Controlling the driver.

### 6.3.1 Using PAMC-204 Software

**Note:**


1. When you connect to the driver with RS485 directly, instead of USB, use a terminal with serial command communication, such as Tera Term, because our software ver1.0 does not cover direct connection.
2. One PAMC-2024 can drive only one motor with one channel. When you drive another motor, the driver automatically stops the current motor driving.

#### Software Installer

\*\*PAMC-204 Software Installer can be downloaded from the link below.

-><https://github.com/mechano-transformer/PAMC-204>


#### Software window explanation.




No	Name	Function
1	Version	Shows the software's version number
2	Port#	Currently connected serial port
3	Connect	Port selection
4	Status	Shows whether the address exists in the drivers' network or driving channel and direction
5	Pulse/Sec	Set the frequency of the driver. The frequency range is 1-1500.
6	# of Pulses	Set the number of pulses to drive during pulse driving mode. The maximum pulse is 9999.
7	Pulse/Continuous	Driving mode selection
8	Channel Selection	Choose which axis to output
9	Address/Scan address	Select the address of the driver to output. If the address does not exist in the network, all other buttons will be disabled. [Scan address] can scan the addresses of all connected drivers
10	Voltage Setting/Voltage set	Change the output voltage. Use this button to adjust the output voltage to higher value for faster movement or smaller value for minute movement. <i>Note: the button [set voltage] must be pressed to apply the change.</i>
11	+	Drive the motor for plus rotation.
12	-	Drive the motor for minus rotation.
13	STOP	Stop the driving operation.
14	EXIT	Close the software.

Using the software.


1. Connect the driver to the PC using USB cable or using RS485 line.
2. Open the software.
3. Press the connect button to open serial port setting window.




4. Select the port of the driver and press OK




- If successful, the window will show the addresses of connected drivers.




- Select the address of the desired driver.




- To change the output voltage, select the desired output voltage level and press the button [Set voltage]. If the button is not pressed, the output voltage will remain unchanged.




- Set the frequency and driving mode between [Pulse] and [Continuous]. For pulse mode, set the desired number of pulses to drive.




9. Select the desired channel.




10. Press the [+ ] button for plus rotation or [- ] button for minus rotation.



11. If the driving mode is continuous, press the [stop] button to halt the driving operation.




12. Press [exit] to shut down the software.



Note:

If the drivers are disconnected while using the software, there are risks of errors and timeouts occurring. For such cases, please press the arrow button as stated below or restart the software.



### 6.3.2 Using Tera Term

1. Connect to the driver using USB cable.
2. Set the terminal and serial port settings as follows:

Communications		PAMC-204/204 RJ
Newline	Receive	CR + LF
	Transmit	CR + LF
Local Echo		Check

Serial port settings

Communications	PAMC-204/204 RJ
Baud Rate	115200 bps
Data Bit	8 Bit
Parity	None
Stop Bit	1 Bit
Flow Control	None
Delimiter	CR + LF

3. Enter the desired command and press [ENTER]. (Refer to section 6.4 and section 6.5 for command list and details)

**Note:**

1. One PAMC-204 can drive only one motor at the same time.
2. When the driver drives a motor with a channel, inputs of the drive commands to activate another channel are invalid.

## 6.4 Command List

Below is a list of commands that can be sent to the driver.

No	Command	Details
1.	ExxINF	Check Firmware Version
2.	Exx	Check if the driver with address exists in network
3.	ExxSETADDRnn	Change driver's address
4.	ExxDACnnnn	Set drive voltage
5.	ExxNRnnnnnyyyyz ExxNRnnnnXyyyyyyz	+Rotation drive Command
6.	ExxRRnnnnnyyyyz ExxRRnnnnXyyyyyyz	-Rotation drive Command
7.	ExxS	Stop the current specific driving operation
8	ExxST?	Check current driving operation status
9	ExxTXFINn	Enable or disable driven pulse number reply after stopping driving operation
10	ExxSNO?	Check the driver serial number
11	ExxAB	Stop a motor driven by the specific driver
12	ExxmACnnnn	Set acceleration*
13	ExxmAC?	Check current acceleration*
14	ExxmDHnnnn	Set the home position
15	ExxmDH?	Check the home position*
16	ExxmMD?	Check the status of operation complete*
17	ExxmMVn	Move continuously
18	ExxmMV?	Check the motion condition*
19	ExxmPAnnnn	Move to a target position
20	ExxmPA?	Check the target position(absolute)*
21	ExxmPRnnnn	Move to a relative position
22.	ExxmPR?	Check the target position(absolute)*
23.	ExxmST	Stop the specified motor moving*
24.	ExxmTP?	Check the current position*
25.	ExxmVAnnnn	Set the moving speed*

26.	ExxmVA?	Check the moving speed*
-----	---------	-------------------------

\* These commands are executed in motion.  
 They can be used with firmware ver0.2.2 and later

## 6.5 Command Description

Below is the detailed description of commands listed in section 6.4.

### ExxINF

<b>Description</b>	Check firmware version	
<b>Syntax</b>	ExxINF	
<b>Detail</b>	This command allows users to confirm the current firmware version of the driver. Use this command to read the firmware version for reference when contacting technical support.	
	<b>Argument</b>	<b>Value</b>
	xx	01~32
		<b>Description</b>
		Driver's possible address
<b>Example</b>	E01INF	(Send command to driver)
	>PAMC-NEWTYP	(Driver reply with firmware version
	Ver:0.2.2(115200bps)	number)

## Exx

<b>Description</b>	Check if driver with xx address exist in network		
<b>Syntax</b>	Exx		
<b>Detail</b>	This command allows users to confirm if there is any PAMC-204 or PAMC-204-RJ connected to the network or PC.		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
<b>Example</b>	E01		(Send command to driver)
	>E01OK		(Driver replied back)
	E02		(Send command to driver)
	>		(No response)

## ExxSETADDRnn

<b>Description</b>	Change the address of connected driver		
<b>Syntax</b>	SETADDRxx		
<b>Detail</b>	This command allows users to change the address of connected driver. <b>Note: Use a single driver setup (section 6.2.1) to change the address of the driver</b>		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Current driver's address
	nn	01~32	Driver's possible new address
<b>Example</b>	E01SETADDR02		(Send command to E01 driver to change address to E02)
	>E01SETADDR02		(Driver replied, address change successful)

## ExxDACnnnn

**Description** Change the voltage output of the driver

**Syntax** ExxDACnnnn

**Detail** This command allows users to change the output voltage of the driver. For precise minute movement, set the voltage level below 100V. It is recommended to set output voltage to 70V for minute movement. For fast movement, set the output voltage to 100V and above.

Argument	Value	Description
xx	01~32	Driver's possible address
nnnn	4095	150V
	3750	140V
	3450	130V
	3200	120V
	3000	110V
	2700	100V
	2450	90V
	2200	80V
	1900	70V

**Example** E01DAC4095 (Send command to change driver E01 output voltage to 150V)  
 >E01OK (Driver replied, voltage change successful)

## ExxNRnnnnnyyyyz / ExxNRnnnnXyyyyyyz

**Description** +Rotation drive command

**Syntax** ExxNRnnnnnyyyyz  
ExxNRnnnnXyyyyyyz

**Detail** This command allows users to order a specific driver and one of its channels to drive the connected motor for + rotation movement. The range of frequency possible is between 1~1500Hz. The possible number of pulses is 0001~9999. The syntax X commands the driver to drive with number of pulses in range 000001~999999. If the number of pulse input is 0, the driver will drive the motor for + rotation movement continuously until stop command is given.

Argument	Value	Description
xx	01~32	Driver's possible address
nnnn	0001~1500	Driving frequency
yyyy	0000~9999	Number of pulses driven
yyyyyy	00000~999999	(Note: 0000 = continuous driving mode,
z	A~D	X: extension command for 6-digit pulses) Driving channel (A: CH1, B: CH2, C:CH3, D:CH4)

**Example** E01NR15001500A (Send command to driver E01 to drive the motor of CH1 to + rotation with frequency 1500HZ with 1500 pulse)  
>E01OK (Driver replied, command received successfully)

E01NR15000000A (Send command to driver E01 to drive the motor of CH1 to + rotation with frequency 1500HZ continuously)  
>E01OK (Driver replied, command received successfully)

(Send command to driver E01 to drive



the motor of CH1 to -rotation with frequency 1500HZ continuously)  
 (Driver replied, command received successfully)

**>E01OK**

**E01RR1500X100000A** (Send command to driver E01 to drive the motor of CH1 to - rotation with frequency 1500HZ with 100000 pulse)

**>E01OK** (Driver replied, command received successfully)

## ExxS

<b>Description</b>	Stop current driving operation
<b>Syntax</b>	ExxS
<b>Detail</b>	This command allows users to stop the driving operation of the specific driver. This command is essential when driving the motor in continuous driving mode.

	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
<b>Example</b>	E01S		(Send stop command to driver E01 during continuous driving mode)
	<b>&gt;E01FIN1456</b>		(Driver replied, stop command successful. The number of pulses driven will be returned to terminal)

## ExxST?

<b>Description</b>	Check current driving operation status
<b>Syntax</b>	ExxST?
<b>Detail</b>	This command allows users to check the driver's current driving operation status.

Below is the list of returned replies:

S: Currently stopped

NRnnnnz: Currently rotating clockwise direction (+)

RRnnnnz: Currently rotating clockwise direction (+)

\*\*nnnn: Driving frequency, z: Driving channel

	<b>Argument</b>	<b>Value</b>	<b>Description</b>
<b>Example</b>	xx	01~32	Driver's possible address
	E01ST?		(Send check driving operation status command to driver E01(currently stopped))
	>E01S		(Driver replied, currently stopped)

## ExxTXFINn

<b>Description</b>	Enable or disable driven pulse number reply after stopping driving operation
<b>Syntax</b>	ExxTXFINn
<b>Detail</b>	This command allows users to set whether the driver will send number of pulses driven after stopping. Default setting is 0(OFF). If the number of pulses driven is required, set to 1.

	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	n	0	Disabled
		1	Enabled

<b>Example</b>	E01TXFIN0	(Send command to disable the driven pulse transmission from driver E01)
	<b>&gt;E01OK</b>	(Driver replied, no driven pulse will be transmitted after stopping driving operation)
	E01NR15000000A	(Send command to driver E01 to drive CH1 motor with 1500Hz speed continuously)
	<b>&gt;E01OK</b>	(Driver replied, start driving operation)
	E01S	(Send command to driver E01 to stop driving operation)
	<b>&gt;</b>	(Driver stopped, no transmission)
	E01TXFIN1	(Send command to enable the driven pulse transmission from driver E01)
	<b>&gt;E01OK</b>	(Driver replied, driven pulse will be sent after stopping driving operation)
	E01NR15000000A	(Send command to driver E01 to drive CH1 motor with 1500Hz speed continuously)
	<b>&gt;E01OK</b>	(Driver replied, start driving operation)
	E01S	(Send command to driver E01 to stop driving operation)
	<b>&gt;E01FIN1023</b>	(Driver stop and transmit the driven pulse numbers)

## ExxSNO?

**Description** Check the driver serial number

**Syntax** ExxSNO?

**Detail** This command allows users to check the driver's serial number. The serial number is also printed on the top seal of the driver. Please include the serial number during any inquiry.

	Argument	Value	Description
	xx	01~32	Driver's possible address
<b>Example</b>	E01SNO?		(Send check serial number command to driver E01)
	>E0110059		(Driver replied, serial number is 10059)

## ExxAB

**Description** Stop a motor driven by the specific driver

**Syntax** ExxAB

**Detail** This command allows users to stop motion of a motor with any channel of the specific driver.

	Argument	Value	Description
	xx	01~32	Driver's possible address
<b>Example</b>	E01AB		(Send stop command to driver E01 during continuous driving mode. The driver dose not reply.)

## ExxmACnnnn

<b>Description</b>	Set acceleration		
<b>Syntax</b>	ExxmACnnnn		
<b>Detail</b>	This command allows users to set the acceleration of desired motor channel. The unit for this parameter is steps/sec <sup>2</sup> . The higher the number, the faster the speed of motor reaching the set velocity parameter.		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
	nnnn	0~150000	possible acceleration value
<b>Example</b>	E011AC100000		(Send the command to driver E01 to set the acceleration of CH1 motor to 10000. The driver does not reply.)

## ExxmAC?

<b>Description</b>	Check current acceleration		
<b>Syntax</b>	ExxmAC?		
<b>Detail</b>	This command allows users to confirm the acceleration value of a motor of the specified channel connected to the driver.		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
<b>Example</b>	E011AC?		(Send the check acceleration for CH1 motor command to driver E01.)
	>10000		(The driver replies with the acceleration value of the motor of CH1 as 10000.)

## ExxmDHnnnn

<b>Description</b>	Set the home position
<b>Syntax</b>	ExxmDHnnnn
<b>Detail</b>	This command allows users to set the home position as an absolute value of a motor connected to the specified channel of the driver.

Argument	Value	Description
xx	01~32	Driver's possible address
m	1~4	a channel address of the driver
nnnn	-2137383648 ~ +2147483647	home position within the allowable range

<b>Example</b>	E011DH1000	(Send the command to driver E01 to set the home position of the motor of CH1 of the driver as 1000. The driver does not reply.)
----------------	------------	---

## ExxmDH?

<b>Description</b>	Check the home position
<b>Syntax</b>	ExxmDH?
<b>Detail</b>	This command allows users to confirm the home position of a motor of the specified channel connected to the driver.

Argument	Value	Description
xx	01~32	Driver's possible address
m	1~4	a channel address of the driver

<b>Example</b>	E011DH?	(Send the command to driver E01.)
	>1000	(The driver replies with the home position of the motor of CH1 as 1000.)

## ExxmMD?

<b>Description</b>	Check the status of operation complete
<b>Syntax</b>	ExxmMD?
<b>Detail</b>	This command allows users to confirm if the move operation has been completed or not.

The driver answers 1 when the move operation has been completed, or 0 when it has not. been completed.

	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
<b>Example</b>	E011md?		(Send the command to driver E01.)
	>1		(The driver replies as 1 as the motor of CH1 is stopping.)

## ExxmMVn

<b>Description</b>	Move continuously
<b>Syntax</b>	ExxmMVn
<b>Detail</b>	This command allows users to move a motor connected with the specified channel of the driver continuously.

\*\*When a motor connected to another channel is operated, this command is invalid.

	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
	n	+	moving to direction "+"
		-	moving to direction "-"

**Example**      E011MV+      (Send the command to driver E01.)  
 (The motor moves in the direction + continuously.)

## ExxmMV?

**Description**      Check the motion condition

**Syntax**            ExxmMV?

**Detail**             This command allows users to confirm the motor motion of the specified channel connected to the driver.

The driver answers 0 when the motor is moving, or 1 when it is stopping.

Argument	Value	Description
xx	01~32	Driver's possible address
m	1~4	a channel address of the driver

**Example**      E011MV?      (Send the command to driver E01.)  
 >1                (The driver answers 1 as the motor of CH1 is stopping.)

## ExxmPAnnnn

**Description**      Move to a target position

**Syntax**            ExxmPAnnnn

**Detail**             This command allows users to move a motor connected with the specified channel of the driver to position nnnn.

Argument	Value	Description
xx	01~32	Driver's possible address
m	1~4	a channel address of the driver
nnnn	-2137383648 ~ +2147483647	absolute position within the allowable range

**Example**      E011PA1000      (Send the command to driver E01.)

(The motor moves to absolute position 1000.)

## ExxmPA?

**Description** Check the target position(absolute)

**Syntax** ExxmPA?

**Detail** This command allows users to confirm the target position of the motor connected to the specified channel of the driver.

\*\*The driver answers the target position when the motor is moving. It answers the current position when the motor is stopping.

Argument	Value	Description
xx	01~32	Driver's possible address
m	1~4	a channel address of the driver

**Example**

E011PA? (Send the command to driver E01 as driver E01 is operating.)  
 (The driver answers that the target position of the motor of CH1 is 15400.)

>15400

E011TP? (Confirmation of the current position)  
 >20 (The driver answers the current position.)

E011PA1000 (Send the command to driver E01 stopping)

E011PA? (Check the target position in moving.)  
 >1000 (The driver answers the target position.)

E011ST (Stop driver E01.)

E011PA? (Check the target position in stopping.)  
 >132 (The driver answers the current position.)

E011TP? (Check the current position.)  
 >132 (The driver answers the current position.)

## ExxmPRnnnn

<b>Description</b>	Move to a relative position	
<b>Syntax</b>	ExxmPRnnnn	
<b>Detail</b>	This command allows users to move a motor connected with the specified channel of the driver from the current position to nnnn steps.	
	<b>Argument</b>	<b>Value</b>
	xx	01~32
	m	1~4
	nnnn	-2137383648 ~ relative position within the allowable range +2147483647
<b>Example</b>	E011PR1000	(Send the command to driver E01.) (The motor of CH1 moves with 1000 steps in direction + from the current position.)

## ExxmPR?

<b>Description</b>	Check the target position(absolute)	
<b>Syntax</b>	ExxmPR?	
<b>Detail</b>	This command allows users to confirm the target relative position of the motor connected to the specified channel of the driver.	
	**The driver answers the target absolute position when the motor is moving. It answers the current position when the motor is stopping.	
	<b>Argument</b>	<b>Value</b>
	xx	01~32
	m	1~4
<b>Example</b>	E011PR? >15400	(Send the command to driver E01 as driver E01 is operating.)

	(The driver answers that the target absolute position of the motor of CH1 is 15400.)
E011TP?	
>123	(Confirmation of the current position)
E011PR1000	(The driver answers the current position.)
E011PR?	(Send the command to driver E01 stopping)
>1123	(Check the target absolute position in moving.)
E011ST	(The driver answers the target relative position.)
E011PR?	(Stop driver E01.)
>545	(Check the target absolute position in stopping.)
E011TP?	(The driver answers the current position.)
>545	(Check the current position.)
	(The driver answers the current position.)

## ExxmST

<b>Description</b>	Stop the specified motor moving	
<b>Syntax</b>	ExxmST	
<b>Detail</b>	This command allows users to stop motion of a motor connected to the specified channel of the specified driver	
	<b>Argument</b>	<b>Value</b>
	xx	01~32
	m	1~4
		a channel address of the driver
<b>Example</b>	E011ST	(Send stop command to driver E01 during continuous driving mode to stop the motor of CH1. The driver dose not reply.)

## ExxmTP?

<b>Description</b>	Check the current position		
<b>Syntax</b>	ExxmTP?		
<b>Detail</b>	This command allows users to confirm the current position of the motor connected to the specified channel of the driver.		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
<b>Example</b>	E011TP?		(Send the command to driver E01.)
	>15400		(The driver answers that the target position of the motor of CH1 is 15400.)

## ExxmVAnnnn

<b>Description</b>	Set the moving speed		
<b>Syntax</b>	ExxmVAnnnn		
<b>Detail</b>	This command allows users to set the moving speed of a motor connected to the specified channel of a driver.		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
	nnnn	1 ~ 1500	speed(steps/sec.) within the allowable range
<b>Example</b>	E011VA1		(Send the command to driver E01.) (The speed of the motor of CH1 is set to 1.)

## ExxmVA?

<b>Description</b>	Check the moving speed		
<b>Syntax</b>	ExxmVA?		
<b>Detail</b>	This command allows users to confirm the motor speed of the specified channel connected to the driver.		
	<b>Argument</b>	<b>Value</b>	<b>Description</b>
	xx	01~32	Driver's possible address
	m	1~4	a channel address of the driver
<b>Example</b>	E011VA?		(Send the command to driver E01.)
	>1		(The driver answers 1 step/sec as the motor speed.)

## 6.6 Error Description

If an incorrect command or incorrect parameter was sent to the driver, the driver will reply with error message. Refer to the table below to determine the cause of error.

Error Message	Description
Error Value Range	Value of number entered during setting voltage is out of range
ERROR	Rotation argument is incorrect. Frequency argument is out of range. Channel set is out of range. No such command exists.
ERROR1	No such command exists.
ERROR4	When setting pulse number with 6 digits, the number of pulses is out of range
ERROR5	When setting pulse number with 4 digits, the number of pulses is out of range
BUSY	The driver is in a driving operation. Stop current operation before entering new command.